

Aussie Shade & Hot Houses

Installing Rain-Frost Cover OR a Shade Cap

1. Pull the Rain/frost or shade cap over the structure. The single centre eyelet is to the rear wall and the two eyelets should be either side of the doorway.
2. Tie a loop in the end of each rope and place the loop under the foot of the pipes below each eyelet.
3. Run the rope up the sides to the eyelet and secure to the eyelet.
4. When removing the rain frost cap, untie the ropes from the eyelet and leave them coiled at the foot each post.

