

## Aussie Shade & Hot Houses

### Installing Solar Inserts

1. The Solar Inserts fit to the gable ends on the inside of the frame.
2. Hold or clamp the Solar Insert in position and mark the frame through each eyelet.
3. Hold the Stayput Fastener centred over the mark and mark the screw holes.
4. Drill the screw holes then fit the Stayput Fasteners. The curved adaptors fit behind the Stayput Fasteners when fitted to the pipe. No curved adaptor when fitted to a fitting.
5. Solar Inserts are now ready to use as required.

